

Series 7 Patch - (Build version 756)

=====
=====

1.IMPORTANT INFORMATION

2.WARNING

3.Installation Instructions

+++++

1.IMPORTANT INFORMATION

This patch should only be installed on a Series 7 device that is of build version 750 or greater.

Check the version by going into the main menu, information, About netBook. The Build version should be listed in the format

ASCII (Build XXX)

The patch updates the operating system to the latest manufactured release

2.

WARNING!!!

KEEP THE UNIT POWERED UP FROM THE MAINS, USING THE ADAPTOR,
THROUGHOUT THE UPDATING PROCESS!!

ANY INTERRUPTION TO THE POWER COULD LEAD TO AN UNUSABLE
MACHINE!

3.Installation Instructions

1.Ensure that you have backed up all your data

2.Copy the files Rom_4mb.img and Update.exe to the root of C:\ on your Series 7 using PsiWin or Compact Flash.

3.Ensure that the Series 7 is powered up from the mains using the DC Jack

4.Run Update.exe, by double tapping it, to install the

patch to your Series 7

5.You will be prompted with the question " Have you backed up your data?" If you have done so, tap OK to continue

6.You will then be prompted to start the process. Tap OK to continue

7.The Series 7 screen will become black and you will see an indication of the upgrading occurring

8.Upon completion, a Green screen with PASS should be observed

9.You then need to remove the DC jack, the main battery and the backup lithium battery. Then re-insert the main battery to re-boot your Series 7.

10.Your unit should now be updated to Build version 756